

| Article  | Collection   |
|--|--|
| FOCUS  | AUTUMN/WINTER 25-26  |
| Count Yarn   | Custom Code  |
| NM. 19/22000                                       | 51061090   |
|  |  |
| Composition<br>90% WO 10% PVA                      | Washing Symbols  |
| 2070 WO 10701 VA                                   |  |
| Made In  |  |
| MADE IN ITALIA                                     |  |
| Type of yarn                                       | Dying process  |
| Innovative Carded and Ultra-Light Yarn             | Tops Dyed  |
| Type of knot                                       | Type of packing  |
| No knot  | Cone of about 1,0/1,2 kg - Box of 18 cones   |
| Use  |  |
| Use one plie on knitting machine gauge 12          |  |
| Do not use contrasting colors with stripes knittin | g  |
| Knitting   | We suggest to use machines with electronic power pack of the yarn.   |
| Uniformity   | The uniformity of yield and of the color are guaranteed for the single dye lot;<br>for each dye lot it is important to inspect each yield and each color.<br>In order to achieve uniformity with sizes, look and handle please kindly proceed<br>always with careful trials for yield on each color taken from production.   |
| Yield/Pilling                                      | Knitting stitch density and washing instructions are going to considerably<br>influence the final result; we suggest to make trials first in order to value<br>pilling and yield of the garment.   |
| Washing  | <ul> <li>PLEASE FOLLOW CARREFULLY WASHING INSTRUCTIONS</li> <li>YARN WITH SOLVRON (PVA) WATER-SOLUBLE FILAMENT</li> <li>Do not effect any type of pre-ironing in order to avoid to crystallizing of Solvron.</li> <li>The phase of washing of garment must be effected following these steps:</li> <li>1 - First short wash (about one/two minutes time) with warm water (40 degrees) with neutral milling soap. It is important to use a big quantity of water in order to eliminate completely Solvron presence in water during washing;</li> <li>2 - Water discharge;</li> <li>3 - Light centrifuge;</li> <li>4 - Slow treatment in cold water for approx 2 min with silicone cationic softener</li> <li>5 - Water discharge</li> <li>6 - Dry in tumbler</li> <li>Treatment to be effected always with garments on the reverse.</li> <li>We suggest, if necessary, to act on the knitting stitch density and on the time of treatment in order to obtain a final result according to your exact needs.</li> </ul> |
| Waste  | It is normal a waste of 3-5%.  |
| Claim  | We do not accept any claim for more than 5 kilos of knitted quantity for each dye lot.   |